

RetroBuster V1.1

www.clod.parts
www.bentaxlebill.com
CP-020

Parts List – Rear Lockout		
Item	Qty	Name
1	2	M3x12 Button head screw
2	2	M3 Lock nut
3	1	G10 Lockout

Lockout Setup

- You will need to swap your steering hubs as shown in the picture.
- With the text side facing up, slide up the G10 Lockout (#3) to the axle tubes, the lockout will go just under the locknuts on your axle tube.
- This is a very tight fit, but it will go in.
- Align the holes with your steering knuckles.
- Use the included M3x12 Button head screws (#1) and place them through the G10 Lockout hole from the bottom going through the steering knuckles. Secure with the included M3 Lock nuts (#2)

This lockout has not been verified on aftermarket parts.

